

---

## Gira G1 demo mode

The key functions of Gira G1 can be demonstrated and tried out in demo mode. In addition to operation of the KNX building functions of the door communication system and weather forecast, some settings can also be made on the Gira G1. This enables you to define the sequence of the tiles or your own favourites, for example.

You can put any Gira G1 in Demo mode by using a microSD card with the demo project in the Gira G1. Configured devices can also be used. An existing project on the Gira G1 is not changed or influenced by operation in demo mode.

Please ensure that the language version of the demo mode matches the language selected on the Gira G1. If, for example, you would like to operate the demo mode in English, "English" must be set as the display language on the Gira G1. If the language versions do not match, the demo mode will be shown in German.

---

### Power supply

The Gira G1 is supplied with power in the demo mode via the PoE insert: For this reason connect the PoE insert either to a PoE injector or a PoE-capable switch.

(An internet or network connection is not required for the demo mode.)


---

### Preparing the microSD card

The demo mode of the Gira G1 is started if a microSD card with a special demo project is inserted in the device. The demo project is available from the Gira homepage at [www.download.gira](http://www.download.gira).

The microSD card with the demo project must remain in the Gira G1 for the entire duration of the demo mode.

- 1 Format the microSD card (max. 32 GB) with the file system FAT32.  
Important: When formatting the microSD card, please deactivate the function "Quick Format".
- 2 Download the ZIP file with the demo mode from the Gira homepage.
- 3 Unpack the ZIP file.
- 4 Copy the folder "Gira" with all its subfolders to the microSD card (there may be no other files on the microSD card).
- 5 Insert the microSD card into the Gira G1. The slot for the microSD card is located on the rear of the device in the bottom right corner. Ensure that the microSD audibly engages.
- 6 The demo mode starts automatically as soon as the Gira G1 is connected to a power supply.



---

## End demo mode

To end the demo mode please remove the microSD card from the Gira G1. To remove the microSD card press the microSD slightly into the device to unlock the card. You can then simply pull out the microSD card. The Gira G1 can now be used as normal again.

## Using an SD card adapter

An SD card adapter is included with many microSD cards. It is not required for operation in the Gira G1. The adapter is required if you would like to use the microSD card in the SD card slot of your notebook.

